



How do I change my Single Rate Tariff?

All meters are manufactured to be set in Single Rate mode by default and the tariff is set at 15.00 pence per unit. You can quickly and easily change this tariff by following these steps:

- Place the Programming Card on the front of the meter where it says "Hold Card Here" until the LCD display shows the following display:



- Now remove the Programming Card and press the **RED** Button 24 times. This will scroll through several different settings such as Time and Date etc..
- You will then see the current tariff rate set on the meter (factory default is 15.00 pence per unit)



- You will notice the first number (in this case a zero) will be flashing.
- Press the **RED** button to move to the next digit to the right.
- To change the number you should press the **BLUE** button until you have the correct number and then press the **RED** button to move to the next digit to the right.
- Keep doing this until you have changed to the desired tariff rate

01803 297179 | 01803 299488

- Once you are happy with this continue to press the **RED** button until you see the screen that shows END



To check that the tariff rate is set correctly you can press the GREY Display Cycle button next to the LCD display 3 times to see the r1 tariff rate

