



SMITHS COIN METER - NEW £1.00 COIN

ADJUSTMENT INSTRUCTIONS



What you will need:

New £1.00 coin blank
Correct size file

New £1.00 coin blanks and correctly sized files are available from us. Please contact us for details.

Whether or not the coin action on your Smiths Reconditioned Coin Meter will need adjusting will depend upon the type of coin action you have. Generally an "X" type coin action will not require adjustment; if it does it's only a slight adjustment. However, all of the "Y" type coin actions will need some slight adjustment.

For guidance as to whether you have an "X" or "Y" type coin action see our document: Smiths Coin Meter – Type of Coin Action

You do NOT need to uninstall the meter to make the adjustment. However, you will need to remove the coin action to carry out the small amount of filing to the outer edge of the coin action. See guidance on removing/replacing coin action on page 2.

Procedure to adjust the coin action to accept the new £1.00 coin:

1. Make a note of the unit per coin setting prior to removing the coin action (See document: Coin Meter – Smiths – upc adjust LH for advice)
2. Take out the coin action (see guidance on page 2)
3. file a small amount from the outer edge of the coin action - offer up the £1.00 blank, once blank fits do not file any further
4. Replace the coin action (see below)



Visit our website to see our video showing the simple adjustment needed: www.electrictimers.co.uk

01803 297179 | 01803 299488



REMOVING/REPLACING THE COIN ACTION

- 1 Remove the cash box from the meter



- 2 Undo the retaining nut on the bottom left hand side of the coin action



Retaining nut

- 3 Remove the metal retaining ring from around the coin action



- 4 Withdraw coin action



5. To replace, return the coin action to the housing, replace the metal retaining ring around the coin action and secure with the retaining nut.

6. Replace the cash box

01803 297179 | 01803 299488