



INSTRUCTIONS TO CONVERT A MODULE FROM GROOVED BRASS TOKENS TO GROOVED SILVER TOKENS

FIRSTLY ISOLATE THE MAINS SUPPLY

To convert a Timer you only need to replace the module front with the new one provided. To do this please follow the instructions below for your particular type of timer.

PLASTIC CASE TIMER (BLACK)

Leave the module in place but remove the large domed silver screw and the four small silver screws and prise off the top of module. Replace this module front with the new one and replace the screws.

If the coin rail falls out during this procedure refer to the diagram on the reverse of these instructions to refit it.

STANDARD METAL CASE TIMER

Remove the large counter sunk screw located beneath the microswitch; the module will then be loosened from the case. Remove the four small silver screws and prise off the top of module. Replace this module front with the new one and replace the screws.

If the coin rail falls out during this procedure refer to the diagram on the reverse of these instructions to refit it.

DOUBLE CASE AND SLIMLINE METAL CASES

Slide the module from the case. Remove the four small silver screws and prise off the top of module. Replace this module front with the new one and replace the screws.

If the coin rail falls out during this procedure refer to the diagram on the reverse of these instructions to refit it.

01803 297179 | 01803 299488

