

Wall Mounted Ironing Centre

Installation Instructions

IMPORTANT.

THE BOARD MUST BE PROPERLY SECURED TO A STABLE VERTICAL SURFACE. IT MAY BE NECESSARY TO USE OTHER FORMS OF FIXING OTHER THAN THOSE SPECIFIED, ESPECIALLY WHEN FIXING TO A STUD PARTITION OR HOLLOW WALL.

The word 'wall' is used to describe a vertical surface i.e. wall, wooden panel, door etc. When fixing to wood, it may not be necessary to plug the fixing holes.

1. Draw a 20cm / 8" horizontal line where the board is to be situated. A minimum height of 100cm / 40" is recommended for use when standing or 84cm / 33" if seated (see sketch).
2. With the board open, position the top of the bracket which is attached to the board, level with the line. Mark the two top fixing screws, then remove the board.
3. Drill, plug and fit the screws. Do not fully tighten the screws - allow 10 mm protruding from the wall.
4. Hang the board on the wall and mark the remaining fixing screws. Remove the board, drill and plug these holes then replace the board.
5. Tighten all screws.

IRON REST - (Optional extra unless purchased with board.)

See diagrams.

The iron rest is designed to sit at the top of the board as shown. If required, it may be fitted to the side of the board to gain more ironing area. Fit the rest after the board has been fitted.

1/ Remove the protective coating covering the tray, then with care, clip the two parts together.

2/ With the board open, position the iron rest at the top, but central, so the inner sides of the rest do not touch the edges of the board. Hold the rest still, and mark the two fixing holes. Drill the wall, and using the wall plus supplied, screw the holder to the wall.

